


AMGO  [®] **Hydraulics**

Original

Installation And Service Manual



TWO-POST LIFT

MODEL: OH-15

CONTENTS


Product Features and Specifications	1
Installation Requirement	3
Steps of Installation	5
Exploded View	25
Test Run	33
Operation Instruction	357
Maintenance	36
Trouble Shooting	37
Lift Disposal	37

I. PRODUCT FEATURES AND SPECIFICATIONS

CLEAR-FLOOR DIRECT-DRIVED MODEL FEATURES

Model OH-15 (See Fig. 1)

- Direct-driven design, minimize the lift wear parts and breakdown ratio
- Dual hydraulic cylinders are designed and manufactured according to high standard, utilizing imported seals
- Self- lubricating UHMW Polyethylene sliders and bronze bush
- Single-point safety release with dual safety design
- Clear-floor design, provide unobstructed floor use
- Overhead safety shut-off device prevents vehicle damage
- Standard adjustable heights accommodate varying ceiling heights



MODEL OH-15 SPECIFICATION

Model	Style	Lifting Capacity	Lifting Time	Lifting Height	Overall Height	Overall Width	Minimum Pad Height	Motor
OH-15	Clear-floor Direct-driven	15,000lbs (6800kg)	90s	72 1/2" - 81 1/2" (1842-2071mm)	174"/198" (4420/5029mm)	150 3/4" (3829mm)	7 1/4" (185mm)	2.0HP

Arm Swings View




Fig. 2

II. INSTALLATION REQUIREMENT

A. TOOLS REQUIRED

↳ Rotary Hammer Drill ($\Phi 19$)



↳ Hammer




↳ Level Bar



↳ English Spanner (12")



↳ Wrench set: (10#, 13#, 14#, 15#, 17#, 19#, 24#, 27#, 30#)



↳ Ratchet Spanner With Socket (28#)



↳ Carpenter's Chalk



↳ Screw Sets



↳ Tape Measure (7.5m)



↳ Pliers



↳ Lock Wrench



↳ Socket Head Wrench (3#, 5#, 8#)



Fig.3

B. Equipment storage and installation requirements.

The equipment should be stored or installed in a shady, normal temperature, ventilated and dry place.

C. The equipment should be unload and transfer by forklift.




Fig.4

D. SPECIFICATIONS OF CONCRETE (See Fig. 5)

Specifications of concrete must be adhered to the specification as following. Failure to do so may result in lift and/or vehicle falling.

1. Concrete must be thickness 7 7/8”(200mm) minimum and without reinforcing steel bars, and must be totally dry before lift installation.
2. Concrete must be in good condition and must be of test strength 3,500psi (245kg/cm²) minimum.
3. Floors must be level with no cracks or holes.




Fig. 5

E. POWER SUPPLY

The electrical source must be 3KW minimum. The source cable size must be 2.5mm² and in good condition of contacting with floor.

III. INSTALLATION STEPS

A. Location of installation

Check and ensure the installation location (concrete, layout, space size etc.) is suitable for lift installation.

B. Use a carpenter's chalk line to establish installation layout of baseplate (See Fig. 6)




Fig. 6

C. Check the parts before assembly.

1. Packaged lift, hydraulic power unit and parts box; (Remark: Outer column is not packed into the machine) (See Fig. 7).



Fig. 7

2. Move the lift aside with a fork lift or hoist, and open the outer packing carefully (See Fig. 8).




Fig. 8

3. Remove aside the top beam assy. (See Fig. 9).



Fig. 9

4. Lift the upper column with a fork lift or hoist, loosen the bolts of the upper package stand, take off the upper outer column, then take out the parts in the inner column (See Fig. 10).



Fig. 10

5. Lift the lower column with a fork lift or hoist, take down the package stand, than take off the lower outer column, take out the parts in the inner column (See Fig. 11).




Fig. 11

6. Move aside the parts and check the parts according to the shipment parts list
(See Fig. 12, Fig. 13)




Fig. 12

103



Fig. 13

Parts of 103

7. check the parts of the parts bag 1 according to parts bag list (See Fig. 14).



Fig. 14



8. Check the parts of the parts bag 2 according to parts bag list (See Fig. 15).



Fig. 15



D. Install parts of extension columns (See Fig. 16).




Fig. 16

E. Install hydraulic cylinder

Wind enough seal tape on the extended straight fitting and 90° fitting, and connecting the fittings, and then install the cylinder into the carriages (See Fig. 17, Fig.18).




Fig. 17




Fig. 18

F. Install columns

Lay down two columns on the installation site parallelly, position the power-side column according to the actual installation site. Usually, it is suggested to install power-side column on the right side of vehicles drive-in. This lift is designed with 2-Section columns. Adjustable height according to the ceiling height and connecting the inner and outer columns.

If the ceiling height is over 198 1/4"(5035mm), it can be installed in a high setting; if the ceiling height between 174 3/8"(4430mm)-198 1/4"(5035mm), it can be installed in the low setting; it is not allowed to install if the ceiling height less than 174 3/8"(4430mm).

1. High Setting, connecting the outer columns with the lower hole (See Fig. 19).




Fig. 19 High setting

2. Low Setting: connecting the extension columns with the upper hole (See Fig.20).




Fig. 20 Low setting

G. Install anchor bolts. Position the columns on the installation layout. Check the columns verticality with level bar, and adjusting with the shim if the columns are not vertical. Do not tighten the anchor bolts at this time. (See Fig.21, Fig.22)




Fig. 21



Note: Minimum embedment of anchors is 5 7/8"(150mm).

Fig. 22

H. Install overhead top beam

1. With help of the hook of top beam, put one side of top beam on top of the extension column and connecting the top beam to extension column by bolts, tighten the bolts. Then assemble the connecting bracket (See Fig. 23).






Fig. 23

2. Assemble overhead top beam, tighten the columns anchor bolts (See Fig. 24).



Tighten the anchor bolts with ratchet spanner with socket



Note: Torque of Anchors is 150N.m.

Fig. 24

I. Installing the limit switch control bar and limit switch (See Fig. 25).




Fig. 25

J. Install safety device (See Fig. 26 & Fig. 27).




Fig. 26 Power-side safety device




Fig. 27 Off-side safety device

K. Lift the carriages up by hand and make them be locked at the same level (**See Fig. 28**).




Fig. 28

L. Install cables

1. High setting cable connection.

1.1 Take out the carriages plastic cover, cable pass through from the bottom of the carriages and be pulled out from the open of carriages, then screw the two cable nuts (See Fig. 29).




Fig. 29

1.2 Connecting cable for high setting (See Fig. 30)




Fig. 30

2. Low setting cable connection. (See Fig. 31).




Fig. 31

M. Install power unit (See Fig. 32)




Fig. 32

N. Install oil hose (See Fig. 33)

(48, 49 Only for high setting)




Fig. 33

O. Install safety cable. (See Fig. 34)

Install safety cable from off-side safety assy. to power-side safety assy., pass through the top beam.




Fig. 34

P. Install wire protective cover (See Fig. 35)




Fig. 35

Q. Install lifting arms and adjust the arm locks

1. Install lifting arms (**See Fig. 36**).
2. Lowering the carriages down to the lowest position, then use the 8# socket head wrench to loosen the socket bolt (**See Fig.37**).
3. Adjust arm lock as direction of arrow (**See Fig.38**).
4. Adjust moon gear and arm locks to make it to be meshed, then tighten the socket bolts of arm lock (**See Fig.39**).




Fig. 36




Fig. 37




Fig. 38
Adjust moon gear




Fig. 39
Locking the bolts after
moon gear and arm lock
engage well.

R. Tighten all the oil hose connectors, fill with Hydraulic oil into the tank. In consideration of Hydraulic Power Unit's durability and keep the equipment running in perfect condition, please use Hydraulic Oil 46#.

S. Install electrical system

220V Single phase motor

1. Connecting the two power supply lines (fire wire **L** and zero wire **N**) to terminals of AC contactor marked **L1, L2** respectively.
2. Connecting the two power wire of Power unit to terminals of AC contactor marked T1, T2 respectively.
3. Connecting A2 terminal of AC contactor to L2 terminal with a single power supply line.
4. Connecting Limit switch: Remove the line of connecting terminal 4# of control button and A1 of AC contactor (see Fig.41). Connecting wire 12# (brow wire) of limit switch with terminal 4# of control button; Connect wire 11# (blue wire) with terminal A1# of AC contactor. Connecting the yellow and green wire to the terminal earth wire of limit switch and terminal earth wire of power unit. (see Fig.42)
5. Terminal #3 of the control button is connected with the terminal L1 of the AC contactor.




Fig. 40





Fig. 41

Motor wire

N
L

4#

Remove this wire before connecting the Limit Switch




Fig. 42

IV. EXPLODED VIEW

Model OH-15




Fig. 43

PARTS LIST FOR MODEL OH-15

Item	Part#	Description	OH-15	NOTE
1	11217466	Power-side column	1	
2	071102	Manual Power unit	1	
3	10209003	Hex Bolt	4	
4	10209033	washer	4	
5	10217002	Hex Nut	4	
6	11217405	Power-side safety cover	1	
7	11217005	Plastic ball	1	
8	11217006	Lock handle	1	
9	10206023A	Hex nut	1	
10	10420026	Lock washer	1	
11	11217004	Main cam lock	1	
12	11217007	Large spacer	2	
13	10217030	Main spring	2	
14	11217009	Main lock	1	
15	10217010	Hex bolt	1	
16	10217011	Hex nut	1	
17	11217012	Safety spacer	2	
18	10217051	Socket bolt	2	
19	11217050	Safety pin	2	
20	10420018	Nylok nut	8	
21	11217069	Hex Bolt	34	
22	10206006	Washer	35	
23	10206023	Nylok nut	34	
24	10420045	Washer	38	
25	1061K074	Protective ring	2	
26	10217013	Hex bolt	8	
27	11217016B	Top Beam Assy. (Left)	1	
28	11217015B	Top Beam Assy. (Right)	1	
29	11420044	Limit plate	2	
30	10209149	Lock washer	12	
31	10420138	Socket bolt	4	
32	11217019	Top pulley	4	
33	10217020	Bronze bush for pulley	6	
34	11217021	Top Pulley Spacer (Short)	4	
35	11217022	Pin for Top Pulley	2	
36	11217023	Pin Spacer (Long)	2	
37	11217024	Oil Hose Support Plate	2	
38	10206009	Plastic Small Pulley	3	
39	10209056	Nylok nut	3	
40	10209046	Hex Bolt	3	
41	11217026	Safety Cable Bracket	2	
42	11217471	Outer Column (L=2356mm)	2	
43	11217406	Off-side safety cover	1	
44	10217008	Safety Spring	1	

Item	Part#	Description	Qty.	Note
45	11217031	Off-side cam Lock	1	
46	10217032	Cable lock hold	1	
47	10217033	Self locking Nut	1	
48	1002185002	Fitting (high setting)	1	
49	1002185001	Hose (high setting)	1	
50	11217029	Small Pulley Bracket	1	
51	10217066	Hex Bolt	3	
52	11217467	Off-side Column	1	
53	11209051B	Adapter 1.5"	4	
54	11209052B	Adapter 2.5"	4	
55	11209053B	Adapter 5"	4	
56	10207045	Anchor bolt	12	
57	10620065	Shim(2mm)	10	
	10201090	Shim(1mm)	10	
58	10217173	Wire Cable L=4856	1	
59	10206025A	Foam Cushion	1	
60	10201005	Split Pin	2	
61	11206129	Control bar	1	
62	11206025C	Connecting pin for control bar	2	
63	11217478	Wire Protective cover 2230mm	2	
64	10206110	M6*35 cup head bolt	6	
	10206079	M6*40 cup head bolt	10	
65	11217473	Wire Protective cover L=1143(high setting)	2	
	11217477	Wire Protective cover L=531(low setting)	2	
66	11217880	Wire Protective cover 1320mm	1	
	11217895	Wire Protective cover 1320mm	1	
67	10217056A	Cylinder	2	
68	10217188	Slider block	16	
69	11217480	Carriage	2	
70	11217054	Carriage Plastic Cover	2	
71	10209009	M6*8 Cup Head Bolt	8	
72	10217053	Protective Rubber	2	
73	10209019	Flat Head Screw	12	
74	11217046B	Arm Lock Bar(Right)	2	
75	11217046C	Arm Lock Bar(Left)	2	
76	10217045A	Spring	4	
77	10217044	Arm Lock	4	
78	10206036	Hair pin	4	
79	10640109	Washer	8	
80	10206032	Snap ring	4	
81	10520023	Snap ring	4	
82	11217047B	Arm Pin	4	
83	10209038	Hex Bolt	6	
84	11217037	Bottom pulley Pin	2	
85	11217036	Bottom Pulley	2	

Item	Part#	Description	Qty.	Note
86	10206156	Tool tray	2	
87	11206154	Rear guard bar	4	
88	10201002	Hex bolt	8	
89	10209034	Lock Washer	8	
90	10209033	Washer	8	
91	10217114A	Rubber pad assy.	4	
91A	10420138	Socket bolt	12	
91B	10209134	Rubber Pad	4	
91C	11680030B	Rubber Pad Frame	4	
92	10217052D	Lifting Arm Assy.	4	
93	11217060A	Extend Straight Fitting	2	
94	10217061A	90° Fitting	2	
95	11217068	Column Reinforce Plate	2	
96	10217454	Wire Cable	1	
97	10206011	Cup Head Bolt	2	
98	10206013	Limit switch	1	
99	11206042	Limit Bar Bracket	2	
100	10209009	Cup Head Bolt	8	
101	10209066	Cable nut M16	8	
102	10217452	Cable Assy.	2	
103	10420029	Cable shim	4	
104	10217195	T-Fitting	1	
105	10217455	Oil hose Assy.	2	
106	10217456	Oil hose Assy.	1	
107	10217189	90 °fitting for power unit	1	
108	10206110	Cup Head Bolt	6	
109	10206079	Cup Head Bolt	12	
110	10217453	Safety Cable	1	
111	10217502B	Parts box	1	
112	1102075001	Cable restrain plate	4	

1. Lifting Arm Exploded View (10217052D)




Fig. 44

Item	Part#	Description	Qty.	Note
1	10206048	Socket bolt	12	
2	10209039	Lock washer	12	
3	10209022	Washer	12	
4	11206049	Moon gear	4	
5	11217122	Outer rear arm	4	
6	10201149	Flat head screw	4	
7	11217123A	Inner arm	4	

2. Cylinders Exploded View (10217056B)




Fig. 45

Item	Part#	Description	Qty.	Note
67-1	10209069	O-Ring	2	
67-2	10209070	Bleeding Plug	2	
67-3	10201029	Support Ring	2	
67-4	10201030	Y-Ring	2	
67-5	10201031	O-Ring	2	
67-6	11217074A	Piston	2	
67-7	10217075	O-Ring	2	
67-8	11217089	Piston rod	2	
67-9	11217077	Piston rod fitting	2	
67-10	10217078	Dust ring	2	
67-11	11217079	Head cap	2	
67-12	10217080	O-Ring	2	
67-13	11217091	Bore weldment	2	

4.3 Manual power unit Explode View (071102)

220V/60Hz, Single Phase




Fig. 46

Parts For Manual Power Unit 220V/60Hz/Single phase (071102)				
Item	Part#	Description	Qty.	Note
1	81400180	Rubber Pad	2	1
2	81400130	Starting capacitor	1	2
3	81400088	Running capacitor	1	3
4	10420148	Cup Head Bolt with washer	4	4
5	81400066	Cover of Motor Terminal Box	2	5
6	81400363	Motor Connecting Shaft	1	6
7	090106	Manifold block	1	7
8	10209149	Washer	4	8
9	81400276	Iron plug	1	9
10	81400259	Red rubber plug	1	10
11	85090142	Socket bolt	4	11
12	81400280	Gear pump	1	12
13	10209034	Washer	2	13
14	81400295	Socket bolt	2	14
15	81400365	O ring	1	15
16	10209152	Ties	1	16
17	85090167	Magnet	1	17
18	81400290	Filter	1	18
19	81400413	Steel Motor	1	19
20	10420070	Push button	1	20
21	41030055	AC connector	1	21
22	81400287	Motor terminal box cover	1	22
23	7111216	AMGO power unit label	1	23
24	81400560	Throttle valve	1	24
25	81400266	Relief valve	1	25
26	81400284	Inner hex iron plug	1	26
27	10720118	Hair pin	1	27
28	81400451	Release valve handle	1	28
29	10209020	Plastic ball	1	29
30	81400421	Release valve nut	1	30
31	81400422	Shim	1	31
32	81400449	Valve Seat	1	32
33	070001	Release Valve	1	33
34	070002	Check Valve	1	34
35	81400366	Oil suction pipe	1	35
36	81400289	Oil return pipe	1	36
37	81400364	Clamp	1	37
38	81400263	Oil tank cap	1	38
39	81400319	Oil tank	1	39

Illustration of hydraulic valve for hydraulic power unit (See Fig. 47)




Fig. 47

V. TEST RUN

1. Adjust synchronous cable (See Fig. 48)

Use Spanner to hold the cable fitting, meanwhile use ratchet spanner to tighten the cable nut.

Make sure two cables are with the same tension so that two carriages can work synchronously.

Fit the plastic hole cover on the lifting head.




Fig. 48

If the carriage does not Synchronize when lifting, please tighten the cable nut.

2. Adjust safety cable

Lifting the carriages and lock at the same height, strain the safety cable and then release a little, and then tighten the cable nuts. Make sure the safety device can always be worked properly.

3. Exhaust air

This hydraulic system is designed to bleeding air by losing the bleeding plug. Lifting the carriages to about 1 meter height, and loose the bleeding plug, the air would be bled automatically, then tighten the plug after bleeding, the lift would work stably and smoothly, otherwise repeat bleeding (See Fig. 49).





Fig. 49

4. Adjust the lower speed

You can adjust the lower speed of the lift if needing: turn the throttle valve clockwise to decrease the lower speed, or counterclockwise to increase the lower speed.



Clockwise to decrease the lower speed.

Counterclockwise to increase the lower speed.

Fig. 50

5. Test with load

After finishing the above adjustment, test running the lift with load. Run the lift in low position for several times first, make sure the lift can rise and lower synchronously, the safety device can lock and release synchronously. And then test run the lift to the top completely. If there are anything improper, repeat the above adjustment.

NOTE: It may be vibrated when lifting at start, lifting it with load for several times, the air would be bled and the vibration would be disappeared automatically.




Fig. 51 Hydraulic System

VI. OPERATION INSTRUCTIONS

Please read the safety tips carefully before operating the lift

To lift vehicle

1. Keep clear of site near the lift;
2. Position lift arms to the lowest position;
3. To shortest lift arms;
4. Open lift arms;
5. Position vehicle between columns;
6. Move arms to the vehicle's lifting point;

Note: The four lift arms must at the same time contact the vehicle's lifting point where manufacturers recommended

7. Press button "**UP**" until the lift pads contact underside of vehicle totally. Recheck to make sure vehicle is secure;
8. Continue to raise the lift slowly to the desired working height, ensuring the balance of vehicle;
9. Push lowering handle to lower lift onto the nearest safety. The vehicle is ready to repair.

To lower vehicle

1. Be sure clear of around and under the lift, only leaving operator in lift area;
2. Press button "**UP**" to raise the vehicle slightly, and then release the safety device, lower vehicle by pushing lowering handle.
3. Open the arms and position them to the shortest length;
4. Drive away the vehicle.
5. Turn off the power.

VII. MAINTENANCE SCHEDULE

Monthly:

1. Re-torque the anchor bolts to 150 Nm;
2. Check all connectors, bolts and pins to insure proper mounting;
3. Lubricate cable with lubricant;
4. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage;
5. Check safety device and make sure proper condition;
6. Lubricate all rollers and pins with 90wt. Gear oil or equivalent;

Note: All anchor bolts should take full torque. If any of the bolts does not function for any reason, DO NOT use the lift until the bolt has been replaced.

Every six months:

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust as necessary, equalizer tension of the cables to insure level lifting.
3. Check columns for plumbness.
4. Check rubber pads and replace as necessary.
5. Check safety device and make sure proper condition.

VIII. TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	<ol style="list-style-type: none"> 1. Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. Height limit switch is damaged 5. AC contactor burned out 	<ol style="list-style-type: none"> 1. Replace button 2. Repair all wiring connections 3. Repair or replace motor 4. Replace the limit switch 5. Replace AC contactor
Motor runs but the lift is not raised	<ol style="list-style-type: none"> 1. Motor runs in reverse rotation 2. Gear pump out of operation 3. Release valve in damage 4. Relief valve or check valve in damage 5. Low oil level 	<ol style="list-style-type: none"> 1. Reverse two power wire 2. Repair or replace 3. Repair or replace 4. Repair or replace 5. Fill tank
Lift does not stay up	<ol style="list-style-type: none"> 1. Release valve out of work 2. Relief valve or check valve leakage 3. Cylinder or fittings leaks 	Repair or replace
Lift raises slowly	<ol style="list-style-type: none"> 1. Oil line is jammed 2. Motor running on low voltage 3. Oil mixed with air 4. Gear pump leaks 5. Overload lifting 	<ol style="list-style-type: none"> 1. Clean the oil line 2. Check electrical system 3. Fill tank 4. Replace pump 5. Check load
Lift cannot lower	<ol style="list-style-type: none"> 1. Safety device are in activated 2. Release valve in damage 3. Safety cable broken 4. Oil system is jammed 	<ol style="list-style-type: none"> 1. Release the safeties 2. Repair or replace 3. Replace 4. Clean the oil system

IX. LIFT DISPOSAL:

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.



AMGO HYDRAULIC CORPORATION

1931 Jo Rogers Blvd, Manning, South Carolina, USA

Tel: (803) 505-6410
Fax: (803) 505-6410

Manual Part No.: 72227903
Revision Date: 2020/09