



Installation: Hang Air-Vac from ceiling using Chain, Cable or threaded rod. Wall brackets can also be used. We recommend placing the bottom of the air cleaner around 11- 12ft if ceilings allow.

OUTER LOUVERS: Turn left or right to create a directional air pattern.

INNER LOUVERS: Can be left horizontal. A few of the bottom louvers may be pointed towards the floor to help lift particulate if desired. Units can be mounted in the middle of the room if preferred.

